

# Installation Instructions

## NPDBL-22RFK/W

### 2' x 2' Recessed Mounting Kit

**READ PRIOR TO ATTEMPTING INSTALLATION**  
**ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION**  
**INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN**

**⚠ IMPORTANT** - This equipment is intended to be installed only by qualified personnel. The installation must be made in accordance with the current edition of the National Electrical Code and all applicable state and local building codes. The final installation must be approved by the appropriate, qualified electrical/building inspector(s). Improper installation may result in a fire or electrical hazard. Be sure the electrical power to the circuit has been disconnected before installing this electrical system.

**⚠ IMPORTANT** - Cet équipement est destiné à être installé uniquement par du personnel qualifié. L'installation doit être faite conformément à l'édition actuelle du Code national de l'électricité et à tous les codes de construction locaux et nationaux applicables. L'installation finale doit être approuvée par un ou plusieurs inspecteurs qualifiés en électricité / bâtiment. Une installation incorrecte peut entraîner un incendie ou un risque électrique. Assurez-vous que l'alimentation électrique du circuit a été déconnectée avant d'installer ce système électrique.

#### INSTALLATION INSTRUCTIONS

1. Turn the power off before installation and cut out 24.37" x 24.37" square in the ceiling.
2. Insert recessed mounting kit into opening and secure with brackets and screws.
3. Remove luminaire's desired knockout and connect wires to input.
4. Insert compatible LED panel or troffer into frame kit, face down.

Compatible Luminaires	
NPDBL-E22	2' x 2' LED Backlit Panel
NPD-E22	2' x 2' LED Edge-Lit Panel
NPTCB-E22	2' x 2' LED Troffer



#### PACKAGING CONTENTS

- (1) 2' x 2' Recessed Frame
- (4) Screws
- (4) Brackets

