

Installation Instructions

NPR-4RTLA

4" Pearl 120V LED Round Trimless Adjustable Retrofit

READ PRIOR TO ATTEMPTING INSTALLATION

ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION

INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN

WARNING: Risk of fire or electric shock. Installation of this retrofit assembly requires a person familiar with the construction and operation of the luminaire's electrical system and the hazard involved. If not qualified, do not attempt installation. Contact a qualified electrician.

WARNING: Risk of fire or electric shock. Install this kit only in the luminaires that has the construction features and dimensions shown in the photographs and/or drawings.

WARNING: To prevent wiring damage or abrasion, do not pinch or damage expose wiring during installation. Keep away from to edges of sheet metal or other sharp objects


WARNING: Risk of fire or electric shock. Do not alter, relocate, or remove wiring, lampholders, power supply, or any other electrical component.

DO NOT MAKE OR ALTER ANY OPEN HOLES IN AN ENCLOSURE OF WIRING OR ELECTRICAL COMPONENTS DURING KIT INSTALLATION.

THIS RETROFIT KIT IS ACCEPTED AS A COMPONENT OF A LUMINAIRE WHERE THE SUITABILITY OF THE COMBINATION SHALL BE DETERMINED BY AUTHORITIES HAVING JURISDICTION.



PACKAGING CONTENTS




Trim



Male Ideal[®]
Quick Connect



LED Lamp Replacement
Marking Sticker



Pearl LED module/retrofit kit
Flood optic (NIO-REFL60) installed



Medium Base
Socket Adapter




Narrow Flood Optic
(NIO-REFL38)



Spot Optic
(NIO-REFL25)

REQUIRED, BUT NOT INCLUDED



NPR-TLMR-4R (4") or NPR-TLMR-6R (6")
Mud Ring




HOUSING DIMENSIONS


Refer to correlation label of luminaire and/or specification sheet at <https://noralighting.com/npr-4rtla>

Install this kit only in luminaires that have the construction features and dimensions described in these instructions, and where the input rating of the retrofit kit does not exceed the input rating of the luminaire.

Max. Number of 12AWG through branch wiring: 8



New Construction



Remodel

	4" Housing Dimensions	6" Housing Dimensions
Max. Branch Circuit Conductor	6 / 8 x 12AWG	
Width	4.03"	6.05"
Height	5.50"	5.51"

Installation Instructions


NPR-4RTLA

4" Pearl 120V LED Round Trimless Adjustable Retrofit


READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN

INSTALLING DESIRED OPTIC


- 1 Pull pre-installed flood optic from heat sink.



- 2 Align desired optic to module and push the optic into place.



- 3 Attach LED module/driver and optic onto trim by threading heatsink.



Installation Instructions

NPR-4RTLA


4" Pearl 120V LED Round Trimless Adjustable Retrofit

READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN


INSTALLATION INTO LED HOUSINGS

REQUIRES: NPR-TLMR-4R OR NPR-TLMR-6R


- 1** Align mud ring to opening. Squeeze friction blades on mud ring and push mudring flush against ceiling.




- 2** Fasten mud ring to drywall using #8 self tapping drywall/sheet metal screws. (screws not included)




- 3** A professional drywall finisher should complete mud in.




- 4** Allow paint to dry and carefully remove cover.



- 5** **IMPORTANT:** Connector is not intended to support weight of the fixture. Please support fixture at all times. Connect orange male connector to female connector of compatible housing listed on the correlation label.



- 6** Insert trim into mud ring, make sure it snaps flush. Turn power back on.



Installation Instructions

NPR-4RTLA


4" Pearl 120V LED Round Trimless Adjustable Retrofit

READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN


INSTALLATION INTO LED HOUSINGS AS LED CONVERSION

REQUIRES: NPR-TLMR-4R OR NPR-TLMR-6R


- 1** Remove existing trim and light bulb from the recessed housing to reveal the medium base socket. If applicable, remove socket from plate. Place the LED Lamp Replacement Marking Sticker inside the housing where visible to the installer. Cut medium base socket cable off existing housing.




- 2** Install male quick connect provided.




- 3** Align mud ring to opening. Squeeze friction blades on mud ring and push mudring flush against ceiling.




- 4** Fasten mud ring to drywall using #8 self tapping drywall/sheet metal screws. (screws not included)



- 5** A professional drywall finisher should complete mud in.



- 6** Allow paint to dry and carefully remove cover.



Installation Instructions

NPR-4RTLA


4" Pearl 120V LED Round Trimless Adjustable Retrofit

READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN


INSTALLATION INTO LED HOUSINGS AS LED CONVERSION

REQUIRES: NPR-TLMR-4R OR NPR-TLMR-6R

- 1** **IMPORTANT:** Connector is not intended to support weight of the fixture. Please support fixture at all times. Connect orange male connector to female connector of compatible housing listed on the correlation label.



- 2** Insert trim into mud ring, make sure it snaps flush. Turn power back on.



Installation Instructions

NPR-4RTLA


4" Pearl 120V LED Round Trimless Adjustable Retrofit

READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN


INSTALLATION INTO LED HOUSINGS AS LED LAMP REPLACEMENT

REQUIRES: NPR-TLMR-4R OR NPR-TLMR-6R


- 1** Remove existing trim and light bulb from the recessed housing to reveal the medium base socket. If applicable, remove socket from plate. Place the LED Lamp Replacement Marking Sticker inside the housing where visible to the installer. Screw medium base socket adapter into medium base socket.




- 2** Align mud ring to opening. Squeeze friction blades on mud ring and push mudring flush against ceiling.




- 3** Fasten mud ring to drywall using #8 self tapping drywall/sheet metal screws. (screws not included)



- 4** A professional drywall finisher should complete mud in.



- 5** Allow paint to dry and carefully remove cover.



- 6** **IMPORTANT:** Connector is not intended to support weight of the fixture. Please support fixture at all times. Connect orange male connector to female connector. Insert trim into mud ring, make sure it snaps flush. Turn power back on.

