

Installation Instructions

NE-983 / NE-984

Emergency LED Remote Head(s)

READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN

⚠ WARNING - This equipment is intended to be installed only by qualified personnel. The installation must be made in accordance with the current edition to the National Electric Code and all applicable state and local building codes. The final installation must be approved by the appropriate qualified electrical/building inspector(s). Improper installation may result in a fire or electrical hazard. Be sure the electrical power to the circuit has been disconnected before installing this electrical system.

⚠ AVERTISSEMENT - Cet équipement est destiné à être installé uniquement par du personnel qualifié. L'installation doit être faite en conformité avec l'édition actuelle du Code national de l'électricité et toutes étatiques et locales codes du bâtiment applicables. L'installation finale doit être approuvée par l'inspecteur en électricité / bâtiment qualifié approprié(s). Une mauvaise installation peut entraîner un incendie ou un risque électrique. Soyez sûr de la puissance électrique vers le circuit a été coupée avant l'installation de ce système électrique.

IMPORTANT SAFEGUARDS

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

1. Disconnect power at fuse or circuit breaker before installing or servicing.
2. Suitable for Wet location.
3. Do not mount in hazardous locations, or near gas or electric heaters.
4. Do not let power cords touch hot surface.
5. Equipment should be mounted in locations and at heights where it will not be subjected to tampering by unauthorized personnel.

SAVE THESE INSTRUCTIONS

6. The use of accessory equipment not recommend by the manufacturer may cause an unsafe condition.
7. Do not use this equipment for other than intended use.
8. All servicing should be performed by a qualified personnel only.


WIRING DIAGRAM



Yellow (V+)
Purple (V-)

Input: 3-12VDC

NE-983




Yellow (V+)
Purple (V-)
Yellow (V+)
Purple (V-)

Input: 3-12VDC

NE-984

INSTALLATION INSTRUCTIONS


1. Connect wires to 3-12VDC supply in accordance with local and national code, yellow wire is for positive, purple wire is for negative. See Wiring Diagram.
2. Use mounting screw holes to mount LED remote head.



Mounting Screw Holes

ADJUSTMENT INSTRUCTIONS

1. Loosen tilting or rotating screw and set remote head to desired position.
2. Tighten tilting or rotating screw to hold position.



Tilting Screw
Rotating Screw