

Installation Instructions

NIO-EXTC2

Extension Collar for Iolite Housings

READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN

ITEM NO.	DESCRIPTION	COMPATIBLE HOUSINGS
NIO-1EXTC2	Extension Collar for 1" Iolite New Construction Housings	NHIOICD-1; NHIOICDCP-1
NIO-2EXTC2	Extension Collar for 2" Iolite New Construction Housings	NHIOICD-2; NHIOICDCP-2
NIO-4EXTC2	Extension Collar for 4" Iolite New Construction Housings	NHIOICD-4; NHIOICDCP-4

⚠ IMPORTANT - This equipment is intended to be installed only by qualified personnel. The installation must be made in accordance with the current edition of the National Electrical Code and all applicable state and local building codes. The final installation must be approved by the appropriate, qualified electrical/building inspector(s). Improper installation may result in a fire or electrical hazard. Be sure the electrical power to the circuit has been disconnected before installing this electrical system.

⚠ IMPORTANT - Cet équipement est destiné à être installé uniquement par du personnel qualifié. L'installation doit être faite conformément à l'édition actuelle du Code national de l'électricité et à tous les codes de construction locaux et nationaux applicables. L'installation finale doit être approuvée par un ou plusieurs inspecteurs qualifiés en électricité / bâtiment. Une installation incorrecte peut entraîner un incendie ou un risque électrique. Assurez-vous que l'alimentation électrique du circuit a été déconnectée avant d'installer ce système électrique.

INSTALLATION INSTRUCTIONS

1. Insert extension collar from below the ceiling. (Figure 1)
NOTE: Collar is not directional, may be inserted into ceiling opening in either direction. Insert in the direction best suited for ceiling, varies per installation.
2. Adjust to where the bottom of the collar sits flush to the ceiling and fasten to the ceiling. (Figure 2)

Figure 1




Figure 2

