
Wall Mounted Installation Instructions NLUD-8334/EM L-Line LED Indirect / Direct Luminaire

READ PRIOR TO ATTEMPTING INSTALLATION Always turn off main power before installation Installation should be carried out by your local electrician


▲ WARNING - This equipment is intended to be installed only by qualified personnel. The installation must be made in accordance with the current edition to the National Electric Code and all applicable state and local building codes. The final installation must be approved by the appropriate qualified electrical/building inspector(s). Improper installation may result in a fire or electrical hazard. Be sure the electrical power to the circuit has been disconnected before installing this electrical system. ▲ **AVERTISSEMENT** - Cet équipement est destiné à être installé uniquement par du personnel qualifié. L'installation doit être faite en conformité avec l'édition actuelle du Code national de l'électricité et toutes étatiques et locales codes du bâtiment applicables. L'installation finale doit être approuvée par l'inspecteur en électricité / bâtiment qualifié approprié(s). Une mauvaise installation peut entraîner un incendie ou un risque électrique. Soyez sûr de la puissance électrique vers le circuit a été coupée avant l'installation de ce système électrique.



CONNECTING MULTIPLE LUMINAIRES

Determine type of system installation prior to mounting.


- LED system can be powered in a single direction with internal quick connects
- LED system can be powered in middle of run with 20' power cord (NLUD-WPC/6W-20, ordered separately)



CHANGING DIRECTION OF LIGHT

Note: LED Luminaires are preset at Direct and Indirect illumination


- 1. Before installing luminaires, determine direction of light.
- 2. Direction of light switch is located on the top of each luminaire.
- 3. Slide switch to the desired direction.



CHANGING COLOR TEMPERATURE

<u>Note</u>: LED luminaires are preset at 3000K in each direction of light

- 1. Before installing luminaires, determine color temperature for each direction of light.
- 2. Color temperature switches are located on the top of each luminaire.
- 3. Slide each switch to the desired color temperature.




Page 1 of 4



Wall Mounted Installation Instructions

NLUD-8334/EM

L-Line LED Indirect / Direct Luminaire




Page 2 of 4



Wall Mounted Installation Instructions

NLUD-8334/EM

L-Line LED Indirect / Direct Luminaire



Page 3 of 4



Wall Mounted Installation Instructions

NLUD-8334/EM

L-Line LED Indirect / Direct Luminaire

READ PRIOR TO ATTEMPTING INSTALLATION ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN


REQUIRES: NLUD-WPC/6W-20 (Ordered Separately)

WALL MOUNTED: DAISY CHAIN MULTIPLE LUMINAIRES (FEED FROM THE MIDDLE OF THE RUN)

▲ TURN OFF MAIN POWER BEFORE INSTALLATION

- Replace the power cord included with wall mount kit (NLUD-8WM/6W) with 20' power cord (NLUD-WPC/6W-20) and adjust to required length.
 Follow steps 1 to 6 on Page 2.
- 2. Follow steps 1 to 6 on Page 2.
- 3. Insert power cord routed behind luminaire through slot in daisy chain bracket (NLUD-WMC) and attach bracket to luminaire. (Figure 1)
- 4. Slide L-Brackets into each end of wall mount plate and install flush against daisy chain bracket with screws and drywall anchors (if needed). (Figure 2)
- 5. Continue routing the power cord behind wire guide brackets and luminaire (B). (Figure 3)
- Remove both end caps on luminaire (B), connect luminaire's quick connects together and attach L-Brackets with thumb screws. (Figure 4)
 Connect power cord to luminaire (B) input wires, connect the separate black wire to black wire from EM driver and tuck wires into the luminaire.
- Place wall mount end cap (included with NLUD-8WM/6W). (Figure 5)

For additional luminaires, use internal quick connects (see page 6). NOTE: Maximum wattage per run is 420W, operating over max. wattage will lead to failure and void warranty.



Page 4 of 4



NLUD-xWM (Ordered Separately)

NLUD-WMC (Ordered Separately)