

Installation Instructions

NSW-720/SC

Ari LED Step Light with Selectable CCT, Interchangeable Face Plate


READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN

⚠ IMPORTANT - This equipment is intended to be installed only by qualified personnel. The installation must be made in accordance with the current edition of the National Electrical Code and all applicable state and local building codes. The final installation must be approved by the appropriate, qualified electrical/building inspector(s). Improper installation may result in a fire or electrical hazard. Be sure the electrical power to the circuit has been disconnected before installing this electrical system.

⚠ IMPORTANT - Cet équipement est destiné à être installé uniquement par du personnel qualifié. L'installation doit être faite conformément à l'édition actuelle du Code national de l'électricité et à tous les codes de construction locaux et nationaux applicables. L'installation finale doit être approuvée par un ou plusieurs inspecteurs qualifiés en électricité / bâtiment. Une installation incorrecte peut entraîner un incendie ou un risque électrique. Assurez-vous que l'alimentation électrique du circuit a été déconnectée avant d'installer ce système électrique.



PACKAGING CONTENTS



Step Light



(3) Wire Nuts




(2) 6-32 x 1" Screws

SELECTING COLOR TEMPERATURE

NOTE: Luminaire is preset to 3000K. Select color temperature prior to installation, as they may have been changed in shipping or handling.

1. Color temperature can be changed by toggling the switch located on the back of the luminaire.



Installation Instructions

NSW-720/SC

Ari LED Step Light with Selectable CCT, Interchangeable Face Plate

READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN


INSTALLATION INSTRUCTIONS

⚠️ TURN OFF MAIN POWER BEFORE INSTALLATION


1 Install 2"x 4" junction box and secure the mounting plate into the junction box by using (2) 8-32 screws. Connect the fixture wires to the junction box as follows:

Black fixture wire to Black (Hot)
White fixture wire to White (Neutral)
Green fixture wire to Green (Ground)


Black	Hot
White	Neutral
Green	Ground



3 Install the face plate in to the mounting plate and secure it using the screws provided.



4 Installation complete.



Installation Instructions

NSW-720/SC


Ari LED Step Light with Selectable CCT, Interchangeable Face Plate

READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN


CHANGING FACEPLATE ORIENTATION

⚠ TURN OFF MAIN POWER BEFORE INSTALLATION


- 1** Remove the (4) screws to separate the mounting plate and the light engine.




- 2** Turn the mounting plate 90°




- 3** Reinstall the mounting plate to the light engine with four screws.



- 4** Install 2"x 4" junction box and secure the mounting plate into the junction box by using (2) 8-32 screws. Connect the fixture wires to the junction box as follows:
- Black fixture wire to Black (Hot)
 - White fixture wire to White (Neutral)
 - Green fixture wire to Green (Ground)



- 5** Install the face plate into the mounting plate and secure it using the screws provided.



- 6** Installation complete.

