READ PRIOR TO ATTEMPTING INSTALLATION ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN

▲ FIRE/ELECTRICAL HAZARD: INSTALL ACCORDING TO NATIONAL ELECTRIC CODE AND ANY APPLICABLE MUNICIPAL CODE REQUIREMENTS. - This equipment is intended to be installed only by qualified personnel. The installation must be made in accordance with the current edition to the National Electric Code and all applicable state and local building codes. The final installation must be approved by the appropriate qualified electrical/building inspector(s). Improper installation may result in a fire or electrical hazard. Be sure the electrical power to the circuit has been disconnected before installing this electrical system.


COMPATIBLE JUNCTION BOXES

Connect wires accordingly: • Black Wire = Live (Hot) • White Wire = Neutral


0-10V Wiring:

• Purple = Dim(+)

• Pink or Grey = Dim (-)



A <u>Risque d'Incendie / d'électricité:</u> Installer selon le code électrique national et toutes LES EXIGENCES RELATIVES AU CODE MUNICIPAL APPLICABLE. - Cet équipement est destiné à être installé uniquement par du personnel qualifié. L'installation doit être faite conformément à l'édition actuelle du Code national de l'électricité et de tous les codes de construction locaux et nationaux applicables. L'installation finale doit être approuvée par un ou plusieurs inspecteurs qualifiés en électricité / bâtiment. Une installation incorrecte peut entraîner un incendie ou un risque électrique. Assurez-vous que l'alimentation électrique du circuit a été déconnectée avant d'installer ce système électrique.



Page 1 of 3





6" Cable Mounted Sapphire III Cylinder


READ PRIOR TO ATTEMPTING INSTALLATION ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN





- 1. Ensure electrical power is off.
- 2. Loosen strain relief on power cord to adjust to desired length. (Figure 1)
- 3. Adjust aircraft cable length by depressing cable gripper. (Figure 1)
- 4. Run power cord through junction box plate. Connect supply wires to power cord, refer to "ELECTRICAL CONNECTIONS" below to make the electrical connections.
- 5. Attach the junction box plate to junction box with screws (not included). (Figure 2)
- 6. Place canopy over junction plate and secure with screws (included). (Figure 3)
- 7. Connect CL2 cable from LED driver to Sapphire reflector. (Figure 4)
- Secure Sapphire reflector to cylinder by screwing the aircraft cable to torsion blade. Make sure aircraft cable is pointing upwards. (Figure 5)
- 9. Push reflector into cylinder until flush.












Page 2 of 3



Installation Instructions

NYLS3-6C 6" Cable Mounted Sapphire III Cylinder



Page 3 of 3

