# **Installation Instructions**


NUDA


# 120V Adjustable LEDUR Under Cabinet with Selectable CCT


READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN


FIRE/FLECTRICAL HAZARD: INSTALL ACCORDING TO NATIONAL ELECTRIC CODE AND ANY APPLICABLE MUNICIPAL CODE REQUIREMENTS. - This equipment is intended to be installed only by qualified personnel. The installation must be made in accordance with the current edition to the National Electric Code and all applicable state and local building codes. The final installation must be approved by the appropriate qualified electrical/building inspector(s). Improper installation may result in a fire or electrical hazard. Be sure the electrical power to the circuit has been disconnected before installing this electrical system.

▲ RISQUE D'INCENDIE / D'ÉLECTRICITÉ: INSTALLER SELON LE CODE ÉLECTRIQUE NATIONAL ET TOUTES LES EXIGENCES RELATIVES AU CODE MUNICIPAL APPLICABLE. - Cet équipement est destiné à être installé uniquement par du personnel qualifié. L'installation doit être faite conformément à l'édition actuelle du Code national de l'électricité et de tous les codes de construction locaux et nationaux applicables. L'installation finale doit être approuvée par un ou plusieurs inspecteurs qualifiés en électricité / bâtiment. Une installation incorrecte peut entraîner un incendie ou un risque électrique. Assurez-vous que l'alimentation électrique du circuit a été déconnectée avant d'installer ce système électrique.









Page 1 of 4




READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN

## **WIRING OPTIONS**


## A. CORD & PLUG

Loosen screw, remove cover from INPUT electrical port and connect cord and plug.




#### **B. ACCESS DOOR WIRING**

- 1. Loosen set screw on access door and remove the door from keyhole slot.
- 2. Assemble 3/8" die-cast connector (included) to the access door and supply the input cables through the die-cast connector.
- 3. Connect supply wires to lumainire's push-in conectors inside luminaire.
- 4. Replace access door and tighten set screw.




## C. FRONT COVER REMOVAL


Luminaire includes (2) screws on the front cover. Gently pry open the cover with a flat head screw driver.  $\frac{1}{2}$  knockouts can be accessed to make electrical connections. Keyhole slots are available for mounting options.




READ PRIOR TO ATTEMPTING INSTALLATION ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN

# **INSTALLATION INSTRUCTIONS**







READ PRIOR TO ATTEMPTING INSTALLATION ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN

# CONTINUOUS RUN INSTALLATION

